



OFS-700

USER'S GUIDE
Fusion Splicer

Warning

1. Do not use non-original battery or AC/DC adapter to power or charge the device.
2. Please remove the AC charging cable and shutdown the device when come across following malfunctions, otherwise will cause the device damage, even person injury, death or fire.
 - ◆ Smoke, odor, noise or abnormal heating
 - ◆ Fluid or impurities inside the device
 - ◆ Device broken
3. You are unauthorized to disassemble the device to do maintenance and repairment, any fault operation may cause the device failure to fix up and make the device out of warranty range.
4. Do not use the splicer in surroundings of flammable liquid/gas. Otherwise may lead to fire, even explosion.

Note

- 1.The device is used to splice silica glass fiber, no other usage. Please read the manual carefully before operate the device.
 - 2.Keep the device away from high temperature or humidity environment.
 - 3.Please do avoid dust when using the device especially in dusty environment.
 - 4.When moving device from lower to higher temperature, please leave device until condensation elimination.
 - 5.Keep the device away from strong vibration and shocks, otherwise will be damaged. Please use a dedicated carrier to transport or store the fusion splicer
- * All is subjected to the physical products, the manual here is only for reference.

Standard Package

Carrying Case



AC/DC Adapter




Fiber Cleaver



Tweezer



Cooling tray



Blowing cleaner



Spare electrodes




CD



Fiber stripper



Introduction



Operation Keyboard

ON/OFF Key

- Power on/off

MENU/CONFIRM Key

- Enter into the menu
- Confirm to save

NEXT Key

- Switch to next option
- Switch X/Y view

Power LED

BACK/ RESET Key

- Return/ Motor reset

START/ADD Key

- Start splicing
- Adjust the parameters



Heating LED

HEAT Key


- Start heating



Splicing Operation



Note: Place fiber between electrodes tip and V-groove end



Function

Press "➡" key to select each sub-menu, then press "⏏" key to enter each setting interface, and "▶" key to set the configuration, finally press "⏏" key to confirm the setting value.

       		
Back	Function 	
Menu/Enter	Arc compensation <input type="checkbox"/>	
	Tension test <input checked="" type="checkbox"/> 	--- If "ON", it will execute tension test automatically after splicing.
Next	Auto starting <input checked="" type="checkbox"/>	--- If "ON", it will auto start splicing after closing the cover.
	Auto heating <input checked="" type="checkbox"/>	--- If "ON", it will auto start heating after closing the cover.
	Force heat <input checked="" type="checkbox"/>	--- If "OFF", when detecting no fiber in heater, it won't heat even press "⏏" key; If "ON", whether detecting having fiber or not, it will heat after press "⏏" key.
10:33 03/07/2019	Reset waiting time ◀ 10s ▶	--- The waiting time for auto reset after closing the lid, and only valid when Tension Test "OFF".

Splice Set

SpliceSet 	
Back	
Menu/Enter	Fiber type ◀ SM ▶  --- Set fiber type based on current fiber type.
	Splice operate mode ◀ Auto ▶  --- Auto, Half-auto, Manual.
Next	Splice program No. ◀ SM-1 ▶  --- Set splicing program number, Max. 800 groups.
	Arc cleaning time ◀ 120ms ▶  --- Clean tiny dust on fiber end by a short arc discharging(0-0.2s).
	Surface angle threshold ◀ 3.0° ▶  --- Set the limit value of fiber end surface angle(0-8°), if over, then prompt error information.
10:33 03/07/2019	Fiber angle threshold ◀ 0.8° ▶  --- Set the alignment angle of left/right fiber(0-4°), if over, then prompts error information.
	Align offset threshold ◀ 0.4μm ▶  --- Set central deviation of left/right fiber(0.0-1.5 μm).
	Loss threshold ◀ 0.05dB ▶  --- If splicing loss is over setting value(0-0.2dB), LCD displays arc compensation.
	Compensation arc time ◀ 1000ms ▶  --- Set arc compensation time, it can reduce splicing loss under certain circumstances.
	Fiber alignment mode ◀ core align ▶  --- Fine align, cladding align and core align(Default).
	Fast splice mode <input type="checkbox"/>   --- ON/OFF, if "ON", fast splicing time can be 7s.
	Force splice <input checked="" type="checkbox"/>   --- If "ON", when detecting fiber angle unqualified, user can press START key to continue splicing, otherwise, it will exit splicing.
	Edit splice program ▶  --- Next page for details.
	Fiber standard ◀ medium ▶  --- Set the Cleanliness standard of cutting fiber.

Splice Set- Edit splice program

Parameter	Value	Control Type	Description
Splice setting		Battery icon	
Pre-Splice time	120ms	Slider	Set the pre-discharge time before final splicing.
Pre-Arc current	701bits	Slider	Set the pre-discharge strength before final splicing.
Splice time	1.6s	Slider	Set splicing time.
Arc current	801bits	Slider	Set the arc current.
Overlap length	8um	Slider	Set the overlap length of fiber propel when splice.
Splice propulsion speed	30um/s	Slider	Set the propulsion speed of motors when splice.
The second arc	<input checked="" type="checkbox"/>	Toggle	Set the second arc on/off.
The second arctime	1.0s	Slider	Display when the second arc on.
The second arc current	801bits	Slider	Display when the second arc on.

Heating Set


The screenshot shows a mobile application interface for setting heating parameters. At the top, there is a navigation bar with icons for Home, Settings, Heating, Information, Manual, Settings, Connections, and Profile. The main menu is titled 'SleeveSet' and includes a battery status icon. The menu items are: 'Heating Program' (set to 1), 'Casing type' (set to 40mm), 'Heating temperature' (set to 210°C), 'Casing diameter' (set to 6mm), and 'Heating time' (set to 25s). A vertical green bar on the right side of the menu items indicates that these values are adjustable. Dashed lines with arrows point from the text annotations to the corresponding adjustable values in the menu.

Control	Item	Value	Adjustment	Description
Back	SleeveSet			
Menu/Enter	Heating Program	1	▲	The device pre-stores heating programs for various protection sleeves, user also can self-define as required.
	Casing type	40mm	▶	10mm-60mm protection sleeve.
	Heating temperature	210°C	▶	Set the Max. temperature during heating.
Next	Casing diameter	6mm	▶	1-8mm.
	Heating time	25s	▼	Set the heating time.

10:33
03/07/2019

Help Info

User can check the explanation of function buttons in Help info interface.



History

The image shows two screenshots of a device's menu system. The top screenshot is the 'History' menu, and the bottom screenshot is the 'Splice Records' menu. Arrows point from text annotations to specific elements in the screenshots.

History Menu:

- Back
- History
- Total Arcnumber 0
- Clear Arccount
- Total records 6
- View records
- Delect records
- Query fault records
- Delete fault records

Splice Records Menu:


No.	Date	Angle	Type	Loss
00001	21-05-18	0.0	SM	0.02
00002	13-07-18	0.0	SM	0.02
00003	13-07-18	0.0	SM	0.01
00004	13-07-18	0.3	SM	0.02
Total: 7		Pages: 2		Current: 1

Annotations:

- Total arc times since last clear.
- Please clear arc times when replacing new electrodes.
- Total Splicing records.
- 10000 data storage. Enter to check splicing date, fiber angle, fiber type, estimated loss.

Maintain

User can do some daily maintenance in Maintain menu, and operate as its prompts in device.




Maintain- Arc correction

When coming across sudden changes of external environment, especially temperature, humidity or air pressure, and aging/dirty of electrode, continuous splicing failure or high loss, unused for a long time, over-used electrodes, or after cleaning/changing electrodes process...etc., then should do arc calibration to adjust the arc intensity, and auto calibrate to standard intensity to reach splicing with low loss and high stability.

1. In Maintain menu, select the "Arc correction" .
2. Place prepared fiber, then close the cover or press "  " key to start arc test.
3. If prompts "Arc current too high" or "Arc current too low", please do it again.
4. If prompts "Arc correction failure", please exit and do it again .
5. If success, then press "  " key to exit.

Note:

- a) The limit cutting angle for arc correction is set separately.
- b) Please do arc correction for several times and do as the prompts shows.



Maintain - Clean Electrodes


If unused for a long time, impurities will attach to the electrodes surface and affect the discharge, so should clean electrodes regularly.

1. Press the power key to turn on the device, then power indicator displays red.

2. Enter "Maintain" menu to select "Clean electrodes".

3. Press "  " key to start auto discharge (5 times), and gasify the impurities through large discharge current in order to stabilize the current and clean the electrodes.

Note: During cleaning, do not touch the electrodes tip with a hard object to avoid damage to the electrodes and affect the splicing.



Maintain-Replace electrodes

← Back	Replace Elect
Menu/Enter	1st: Turn off and replace the old electrodes. 2nd: Ensure that no fiber exist in the vision. 3rd: Press 'Menu' key and follow the prompts. After the operation is completed, the number of discharge will be set to 0.
10:33 03/07/2019	

Loosen screws



Tighten screws

Remove the electrode cover



Place the electrode cover

Remove the old electrode




Install the new electrode

Maintain- Detect system parameters

This function is to do self-diagnosis test and detect several key parameters related to the splicer. And to get better splicing result, we suggest do this operation after system upgrade, electrodes replacement or movement, long-distance transportation and strong vibration, continuous splicing failure or high loss and successive overshoot during alignment.

1. Clean the V-groove with a cotton swab dipped in alcohol, and clean the prepared fiber. This step is important, please ensure to operate as above.
2. Enter "Maintain" menu, then select "Detect system parameters" and press "  " key to enter.
3. Place the prepared fiber and close the cover, then press "  " key to start system calibration.
4. Usually last 2 minutes, if fails, please follow the prompts to correct, and repeat step 1 to self-detect again.
5. Press "  " key to exit system calibration if success.



Fusion Splicer Cleaning

V-groove



Objective Lens



Fiber Presser



The Heater



- When cleaning, keep the device off
- Use cotton swabs dipped in pure alcohol

- Do not touch the electrode tips
- Clean excess alcohol with dry cotton swabs


System

The screenshot shows the 'System' settings menu. At the top is a navigation bar with icons for Home, Power, Fire, Information, Mail, Settings, Network, and App Store. The 'System' menu is open, showing a list of settings. A vertical green bar highlights the 'Brightness adjustment', 'Screen flip', and 'Power saving mode' options. Dashed lines connect these options to their respective descriptions on the right.

Setting	Value	Description
System		
Brightness adjustment	100%	Adjust the brightness of LCD.
Language selection	English	
Screen flip	Flip	The LCD interface rotates 180° to adapt the LCD in different orientations.
Time setup		Set the current date/time.
Restore factory settings		Restore all system parameters to factory settings.
Power saving mode		Set auto sleep and the time of auto shutdown.
Silent mode	off	Turn on/off the buzzer. (pressing the confirmation key to confirm)
Version		Version information.

Battery Information

Battery information shows on the upper right of LCD, and will present different color and graphics in different battery capacity, and also can be checked in system menu.



Remain 100%



Less than 10%
shows red icon



Charging



Fully charging

Abnormal alignment

Graphics (X/Y axis)	Prompts	Possible reasons	Measures
	Right fiber placement error	Right fiber is not placed in V-groove or cutting length is too short	Place and cut the fiber again
	Left fiber placement error	Left fiber is not placed in V-groove or cutting length is too short	Place and cut the fiber again
	Alignment abnormal	Left/ right fiber is not placed in V-groove	Place and cut the fiber again
	Reset the fiber	Left and right fibers are cleaved too short	Place and cut the fiber again
	Reset the fiber	Left and right fibers are cleaved too long	Place and cut the fiber again
	Optical fiber angle disqualification	Problems in fiber cleaving (protruding tips, burrs, bevels, concave cores, etc.)	Cut the fiber again
			
			
			
	Fiber disqualification	Fiber end face has dust	Clean and place fiber again

Troubleshooting

Abnormal working	Reasons	Measures
Abnormal noise when discharging	Improper installation position of electrodes	Please re-install the electrodes strictly based on the requirements
Discharge delayed or failure	1.Improper installation position of electrodes	1.Please re-install the electrodes strictly based on the requirements
	2.Electrode tips are with silicon oxide	2.Clean the electrode tips or replace the electrodes
Device crashes when discharging	Wrong installation position of electrodes	Please re-install the electrodes strictly based on the requirements
Arc calibration failure	The current environment has a great impact on discharging	If continuously prompts high current, please decrease the "splicing current", then do "arc correction", and vice versa. If arc correction fails many times, please contact the after-sales service.
Fiber alignment failure	1. There is dust on objective lens, LED or V-groove	Clean the objective lens, LED and V-groove, if cannot solve, please contact our after-sales service.
	2. The fault of fusion splicer power system	
Poor quality of splicing point	1. There is dust on the fiber	1. Re-prepare the fiber and splice again
	2. Choose the wrong fiber type or splicing program	2. Choose the right fiber type and splicing program
	3. Big changes of splicing condition	3. Do arc calibration to reach a proper arc intensity
	4. The control motor failure	4. Do system self-detection
No response after press keyboard	Abnormal system operation	Restart the device
No light or blurred in LCD	1. Abnormal system operation	Restart the device, if cannot solve, please contact our after-sales service.
	2. LCD cable is loose or broken	
Failure splicing after discharging	Abnormal discharge or system operation error	Please do arc correction, then continue the splicing, if still cannot solve, please restart the device
Fiber is out of visibility during alignment process.	1. The fiber is placed outside the V-groove	1. Please place the fiber again to ensure it in the V-groove.
	2. Abnormal system operation	2. Enter "Splice Set" → "Splice operate mode" menu, choose "Manual" mode, and select left/right fiber, user can control left/right fiber by direction buttons and move it to the center of visible field, then do system self-detection.

